Heat Flux Unit Converter (W/m², kcal/h·m², Btu/h·ft²)

Convert a heat flux or heat release rate between W/m², kW/m², MW/m², kcal/(h·m²) and Btu/(h·ft²), as used for furnace and heating surface loading.

Method: Unit definitions per NIST SP 811 and the SI Brochure (exact where defined)

Input parameters

Unit system: SI

Parameter	Value	Unit
Heat flux (choose its unit)	11,630	W/m²

Calculated results

Parameter	Value	Unit
watt per square metre	11,630	W/m²
kilowatt per square metre	11.630	kW/m²
megawatt per square metre	0.011630	MW/m²
kilocalorie per hour square metre	10,000	kcal/(h·m²)
Btu per hour square foot	3,686.7	Btu/(h·ft²)

Notes for this case

- 1 kcal/(h·m²) = 1.163 W/m².

Formula and method

$$x_{\text{unit}} = \frac{x_{SI}}{f_{\text{unit}}}$$

Variables

x	Heat flux (choose its unit)	W/m²

Method and standards

Each unit's factor to the SI unit is held once in the unit registry.

Assumptions and limits

- Exact factors where the definition is exact.

References

- Unit definitions per NIST SP 811 and the SI Brochure (exact where defined)

Report details

Report reference	FCC-1ZTX-G20R (the same inputs always give the same reference)
Generated	17 November 2026, 19:57 UTC
Calculator	Heat Flux Unit Converter (W/m², kcal/h·m², Btu/h·ft²)
Method last reviewed	12 November 2026
Software release	FireCAD Calc, release of 17 November 2026
Release checks	2 reference cases of this calculator, computed independently, are checked on every release

Results are for engineering estimation. Verify critical designs against the referenced standards and your own data.

This calculator online

https://calc.firecad.com/general/unit-conversions/heat-flux-unit-converter

Open this case on calc.firecad.com →

Reopens the calculator with the inputs of this report.