Thermal Resistance (R-Value) and U-Value Converter

Convert thermal resistance between m²·K/W, h·m²·°C/kcal and h·ft²·°F/Btu (imperial R-value), with the matching U-value in W/(m²·K) and Btu/(h·ft²·°F).

Method: U = 1/R; unit definitions per NIST SP 811

Input parameters

Unit system: SI

Parameter	Value	Unit
Thermal resistance (choose its unit)	2.0000	m²·K/W

Calculated results

Parameter	Value	Unit
m²·K/W	2.0000	m²·K/W
h·m²·°C/kcal	2.3260	h·m²·°C/kcal
h·ft²·°F/Btu (imperial R-value)	11.357	h·ft²·°F/Btu
U-value 1/R	0.50000	W/(m²·K)
U-value, Btu/(h·ft²·°F)	0.088055	Btu/(h·ft²·°F)

Formula and method

$$U = \frac{1}{R}$$

Variables

R	Thermal resistance (choose its unit)	m²·K/W
U	U-value 1/R	W/(m²·K)

Method and standards

Definitions.

Assumptions and limits

- Steady one-dimensional flow.

References

- U = 1/R; unit definitions per NIST SP 811

Report details

Report reference	FCC-XWKY-8XHF (the same inputs always give the same reference)
Generated	17 November 2026, 19:47 UTC
Calculator	Thermal Resistance (R-Value) and U-Value Converter
Method last reviewed	12 November 2026
Software release	FireCAD Calc, release of 17 November 2026
Release checks	2 reference cases of this calculator, computed independently, are checked on every release

Results are for engineering estimation. Verify critical designs against the referenced standards and your own data.

This calculator online

https://calc.firecad.com/general/unit-conversions/thermal-resistance-unit-converter

Open this case on calc.firecad.com →

Reopens the calculator with the inputs of this report.